




# **Rock-It Speed Entry**

## BINDING MANUAL

MARCH 2024 REV.

# BINDING FEATURES

ROCK-IT SPEED SERIES



## 1. RECLINING HIGHBACK

Makes entry and exit incredibly fast and easy and only requires one hand! No fumbling with ratchet buckles and ladders.

## 2. AUTO OPEN LEVER

Opens strap automatically when highback is lowered. Close easily with one click. Magic!

## 3. PRESSURE RELIEF BUTTON

Press to relax ankle strap pressure and increase circulation on your front foot.




# BINDING FEATURES

FROM CHAIRLIFT TO CHARGING

## IN ▶

1.




Step 1: Step in.


Step 2: Close highback.

Step 3: Close Auto Lever and go!

2.




3.



## OUT ▶

1.



Step 1: Lower reclining highback.


Step 2: Auto Lever opens automatically.

Step 3: Step out.

2.



3.



# SIZE TABLE

ROCK-IT DASH




MP	21	22	23	24	25	26	28
USw	04	05	06	07	08	09	11
				M - L			
	S - M						




- Perfectly Fit
- Centered by Disc / Highback



# FORWARD LEAN



## BASIC SET-UP 1.



# CENTERED MOUNTING



# DISC OPTIONS

HOLE  
PATTERN

DSC003 DASH


4x4






Channel



# ROTATION



# ADVANCED SIZE SETUP



### **Pre Riding Check List:**

- Double check all your binding screws, bolts and straps. All hardware should be securely tightened. A few minutes here will save you an hour on the hill.
- Snowboard specific footwear should be used at all times.
- Know the skier's responsibility code.
- Remember, these bindings are not designed to release.

### **Post Riding Check List:**

- Wipe off your snowboard. Don't bash it in the pavement. Put it where it can easily dry away from direct heat.
- Tune and wax your snowboard. A well tuned snowboard is easier to ride and more responsive. Wax protects your base and makes your snowboard faster, if you use the right kind! We recommend ONE BALL JAY snowboard wax products. We also recommend you tune your snowboard about every 5 riding days or when you want to out shred your friends on the hill.
- Check over your bindings. Re-fasten your straps and buckles. Use a board bag to protect your board and bindings from dirt while in a car rack or travelling.

### **Help?**

[roxy.mervin.com](http://roxy.mervin.com)  
[gnu.com/support](http://gnu.com/support)

### **Warning!**

Snowboarding is an active, outdoor, winter sport that involves inherent risks, which can result in serious, even fatal, injuries. Boarders must be aware of the risks and assume responsibility for their actions. The inherent risks in snowboarding arise from, among other things, variations in snow cover, composition and gradient, possible collisions with fixed and moving, natural and man-made objects, other snowboarders, your snowboard and/or bindings, and include the risk of suffocation. This boot/binding interface is designed so that it does not release, which may increase certain of these risks depending on the particular circumstances. Prior to each use these bindings should be inspected to make sure that parts are not worn, damaged, missing or loose. Even under normal conditions a binding may break which can increase the risk of injury. The risks inherent in the sport of snowboarding can be greatly reduced by wearing protective equipment, by taking lessons, and by riding under control, within your limits and with a buddy at all times. By purchasing and/or using these bindings, you acknowledge and voluntarily assume and accept any and all known and unknown risks while using these bindings and hereby release Mervin Mfg. from all liability.

### **All Roxy Bindings are Guaranteed Against Manufacturer's Defects for 1 year.**

Snowboarding is an active outdoor winter sport that can have a significant risk of personal injury. However, the risk of serious injury can be greatly reduced by taking lessons, riding under control at all times, obeying "your responsibility code" and above all using common sense. The boot/binding interface is designed so that it does not release. It is ROXY's opinion that this is a safe boot binding interface. Your leash should be attached to you at all times. Whether riding, hiking or walking so as to prevent run away snowboards from injuring someone else. Also, please make certain that your snowboard is secure when not being used so that it doesn't inadvertently start down the hill without you attached.





[ROXY.MERVIN.COM](http://ROXY.MERVIN.COM)