

ROXY

BINDING USER MANUAL



VIVA



LOLA

GENERAL INFO

Read this manual. It contains important information to use your bindings

PRE RIDING CHECK LIST

- Double check all your binding screws, bolts and straps. All hardware should be securely tightened. A few minutes here will save you an hour on the hill.
- Snowboard specific footwear should be used at all times.
- Know the skier's responsibility code.
- Remember, these bindings are not designed to release.

POST RIDING CHECKLIST

- Wipe off your snowboard. Don't bash it in the pavement. Put it where it can easily dry away from direct heat.
- Tune and wax your snowboard. A well tuned snowboard is easier to ride and more responsive. Wax protects your base and makes your snowboard faster, if you use the right kind! We recommend ONE BALL JAY snowboard wax products. We recommend you tune your snowboard about every 5 riding days or when you want to out shred your friends on the hill.
- Check over your bindings. Re-fasten your straps and buckles. Use a board bag to protect your board and bindings from dirt while in a car rack or traveling. A board bag will also improve your image by letting people know you are a super tech and dialed snowboarder!

LEASH SAFETY

- In compliance with ISO Code 14573, you are required to use a leash at all times when strapped in. Make sure your leash is securely fastened to you and your binding.

WARNING!


Snowboarding is a hazardous active sport that involves inherent risks which can result in serious and even fatal injuries to yourself or others. Snowboarders must be aware of the risks and assume responsibilities for their actions. The inherent risks in snowboarding arise from, among other things, variations in snow cover, composition and gradient, possible collisions with fixed and moving, natural and man made objects, other snowboarders, your snowboard and/or bindings and include the risk of suffocation. This boot/binding interface is designed so it does not release on impact, which may increase certain of these risks. Prior to each use these bindings should be inspected to make sure that parts are not worn, damaged, missing or loose. Even under normal conditions a binding may break which can increase the risk of injury. Read this instruction manual when installing and prior to using Roxy bindings. Use only snowboard specific boots. A runaway snowboard is a dangerous object and it can cause serious injury or death. You are responsible so be aware. In compliance with ISO code 14573, you are required to wear a leash at all times. The leash must be attached to your bindings baseplate and securely fastened to your body. The inherent risks of snowboarding can be greatly reduced by wearing protective equipment, taking lessons, riding under control, within your limits and with a buddy at all times. By purchasing and or using these bindings, you acknowledge and voluntarily assume and accept any and all known and unknown risks incurred while using these bindings and hereby release Mervin MFG from all liability.

BOOT SIZE


SM Binding: US W 4-7

ML Binding: US W 6.5-11


ATTACHING BINDINGS




STANCE WIDTH & BINDING ANGLES




FORWARD LEAN ADJUSTMENT




STRAP ADJUSTMENT



TOE RAMP ADJUSTMENT



ATTACH LEASH



ROXY

Mervin MFG. North America
100 NE Northlake Way Suite 100
Seattle WA 98105
United States

email: ihaveissues@mervin.com